



# EU07419 | SOOTHING ROSE WATER

Happy skin



© SHADBEESTOCK



NOC= 95.4%  
NATURALITY PROFILE according to ISO 16128 norm

Refreshing & Soothing

Sweet happiness water!

<b>A</b>	Aqua / Water	Up to 100%
	Glycerin	3.00%
	Triethanolamine	0.50%
	<b>SEPIWHITE™ MSH</b>	<b>0.50%</b>
<b>B</b>	<b>SEPICALM™ S WP</b>	<b>1.50%</b>
	<b>AQUAXYL™</b>	<b>1.50%</b>
	Colorant C.I. 16035	0.40%
	Sodium Benzoate	0.30%
	Potassium Sorbate	0.40%
	Rosa Damascena Flower Water - Citric Acid - Sodium Benzoate - Potassium Sorbate	2.00%
<b>C</b>	<b>SEPICLEAR G7™</b>	<b>0.50%</b>
	<b>MONTANOX™ 80</b>	<b>0.50%</b>
	Fragrance	0.08%

With WESOURCE®

**Translucent Rose Fluid / Packaging: Spray**

pH: 7.2

**VISCOSITIES: 1M at RT:** < 50 mPa.s Brookfield LV4-6

**STABILITY:** 1M at RT & 45°C

**FORMULATION ADVICES: Laboratory scale - 2 kg - Silverson**

Weight Phase A with hot water. Place this solution in hot water bath (85°C) until solubilization of **SEPIWHITE™ MSH**. Then cooling phase not agitation necessary. When the solution reaches 55°C add Phase B stir with anchor at 200 rpm Then add Phase B let stir 5 min with anchor at 200 rpm. Check that pH =7,2.

**Refreshing & soothing water.**

*Sweet happiness!*

**SEPICALM™ S WP soothes the skin and stimulates endorphin secretion.**

*(Sodium Cocoyl Amino Acids - Sarcosine - Potassium Aspartate - Magnesium Aspartate)*

Aminoacids biovector enriched with mineral salts. It **protects** the skin **from any type of internal or external stresses** (such as inflammation, UV rays, abrasions...) while exalting it by a **real sensation of well being and comfort** (increase the production of **cutaneous pleasure molecules**, reliefs irritative reactions felt by delicate skin and moisturizes effectively).

**AQUAXYL™ moisturizes and restructures the skin.**

*(Xylitylglycoside - Anhydroxylitol - Xylitol)*

**Harmonization of cutaneous hydric flow.** Water reserves are instantly boosted, water circulation is improved in all skin layers and water loss is reduced (*in vitro* & *in vivo* proven). Mechanism of action validated by cosmetogenomics.

**SEPIWHITE™ MSH lightens and illuminates the skin.** *(Undecylenoyl Phenylalanine)*

A **lightening** active ingredient acting through an **original pathway**. Alpha MSH antagonist ("Melanotropin"), it **decreases effectively the melanic pigments** by **respecting the cutaneous integrity**.

**SEPICLEAR G7™ & MONTANOX™ 80 association allows essential oil solubilization without foaming effect.**

**SEPICLEAR G7™ helps the fragrance solubilisation** *(Heptyl Glucoside):*

**100% bio-based O/W concentrated solubilizer.** Allow the introduction at room temperature of liposoluble compounds such as essential oils & vitamin E. **Non foaming.**

**MONTANOX™ 80 enhances formula transparency** *(Polysorbate 80)*. **Solubilizer.**

**ADDITIONAL INGREDIENTS:** Colorant C.I. 16035; FD&C RED N°40 07700C AT 0.1% (LCW) / Sodium Benzoate: BENZOATE DE SODIUM (MERCK EUROLAB) / Potassium Sorbate: POTASSIUM SORBATE (MERCK EUROLAB) / Rosa damascena Flower Water - Citric Acid - Sodium Benzoate - Potassium Sorbate: EAU FLORALE DE ROSE PRH (HERBAROM) / Fragrance: ROSE NATCO (EXPRESSIONS PARFUMÉES).

More informations available on [seppic.com](http://seppic.com)

**SEPPIC**

All information contained herein is intended merely to demonstrate the utility of Seppic products, and should not be construed as granting license to practice any compositions or methods covered by a patent or a patent application. All information contained in this specific technical documentation is believed to be accurate and has been set up by Seppic according to its own described methods and processes. Seppic however does not assume any liability or risks involved in the use of its products for the preparation and the assessment of the hereinabove formulation since the condition of use are beyond its control. Seppic customer must insure that the duplication of the hereinabove formulation is not infringing any intellectual property rights and that it complies with any regulatory status.

A company  
**Air Liquide**  
HEALTH CARE